

Camcorder Quick Check.

See below a list of camcorder models with A/V-in ports.

The BLACKEYE™ TWO camera comes standard with 3 RCA connectors (also called chinch-connectors) to connect to your recording device. You have to use the A/V cable of your recording device (camcorder, digital hard drive, MPEG4 recorder, etc) to connect the two devices.

For additional or more detailed information refer to the manufacturer's websites or a professional retailer.

(All information without guarantee. Subject to change.)

PAL Systems
NTSC Systems

Page 1-7
Page 7-11

MPEG4 Systems

AIPTEK (PAL and NTSC)

MODEL	A/V-in	MODEL	A/V-in
A-HD 720 P	Yes	Pocket DV M1	No
Pocket DV 6800	Yes	Pocket DV T 100	No
Pocket DV 8800	Yes	Pocket DV T 100 LE	No
Pocket DV 8800N	Yes	Pocket DV T 200	No
Pocket DV 8900	Yes	Pocket DV T 300	No
Pocket DV 4100 M	No	Pocket DV T 300 LE	No
Pocket DV 4500	No	Pocket DV Z 100 Pro	No
Pocket DV 5100 F	No	Pocket DV Z 100 LE	No
Pocket DV 5100 M	No	Pocket DV Z 200 Pro	No
Pocket DV 5300	No	Pocket DV Z 200 LE	No
Pocket DV 5800	No	Pocket DV Z 300 HD	No
Pocket DV 5900	No	Go-HD-720 P	No
Pocket DV 6800 LE	No	HDDV 800	No
Pocket DV 6800 S	No	HDDV 8300	No
Pocket DV 8800neo	No	IS-DV	No
Pocket DV 8800 LE	No	IS-DV 2	No
Pocket DV AHD 200	No	MZ-DV	No
Pocket DV C600 pro	No	Video Sharier VS1	No
Pocket DV H 100	No		

ARCHOS (PAL and NTSC)

MODEL	A/V-in	MODEL	A/V-in
705 WIFI	Yes	405	Yes
704 WIFI	Yes	404	Yes
704 TV	Yes	404 Camcorder	Yes
605 WIFI	Yes	204	No
604 WIFI	Yes	104	No
604	Yes	105	No
504	Yes		

PAL Systems

CANON (PAL)

MODEL	A/V-in	MODEL	A/V-in
Elura 40 MCE	Yes	MVX30i	Yes
G30Hi	Yes	MVX35i	Yes
G35Hi	Yes	MVX330i	Yes
HV10 HD	Yes	MVX350i	Yes
HV20 HD	Yes	MVX4i	Yes
MV5	Yes	MVX40i	Yes
MV5i	Yes	MVX45i	Yes
MV4iMC	Yes	MVX460	Yes
MV5iMC	Yes	MVX830i	Yes
MV6iMC	Yes	MVX850i	Yes
MV430i	Yes	XL1s	Yes
MV500	Yes	XL2	Yes
MV500i	Yes	XLH1	Yes
MV530i	Yes	XM1	Yes
MV550i	Yes	XM2	Yes
MV600i	Yes	V60Hi	Yes
MV630i	Yes	V65Hi	Yes
MV650i	Yes	DC 10	No
MV700i	Yes	DC 20	No
MV730i	Yes	HG10	No
MV750i	Yes	MV800	No
MV830i	Yes	MV830	No
MV850i	Yes	MV880X	No
MV960	Yes	MV900	No
MVX1i	Yes	MV930	No
MVX10i	Yes	MV940	No
MVX100i	Yes	MV950	No
MVX150i	Yes	MVX40	No
MVX2i	Yes	MVX300	No
MVX20i	Yes	MVX200i	No
MVX25i	Yes	MVX450	No
MVX200	Yes	MVX460	No
MVX200i	Yes	MVX800	No
MVX250i	Yes	MVX830	No
MVX3i	Yes		

JVC (PAL)

MODEL	A/V-in	MODEL	A/V-in
GR-D30	Yes	GR-DV70	Yes
GR-D40	Yes	GR-DV700	Yes
GR-D50	Yes	GR-DV4000	Yes
GR-D73	Yes	GR-DV500	Yes
GR-D93	Yes	GR-DV70	Yes
GR-D230	Yes	GR-DV700	Yes
GR-D270EK	Yes	GR-DVX95EK	Yes
GR-D290EK	Yes	GR-DX95EK	Yes
GR-DF430	Yes	GR-DX300E	Yes
GR-DF460	Yes	GR-DX37	Yes
GR-DF470	Yes	GR-DX57	Yes
GR-DF560	Yes	GR-DX75	Yes
GR-DF570	Yes	GR-DX77	Yes
GR-DV3000	Yes	GR-DX78	Yes
GR-DV4000	Yes	GR-DX95	Yes
GR-DV50	Yes	GR-DX97	Yes

GR-DZ7EK	Yes	GR-DVL765	No
GR-PD1	Yes	GR-DVL867	No
GR-VPP9	Yes	GR-DVL9000	No
GR-X5	Yes	GR-DVL9200	No
AMX33	No	GR-DVL9500	No
AMX500	No	GR-DVK9700	No
GR-AX480	No	GR-DVL9800	No
GR-AX680	No	GR-DVP3	No
GR-AX880	No	GR-DVP5	No
GR-D20	No	GR-DVP7	No
GR-D23	No	GR-DVP9	No
GR-D24	No	GR-DVX4	No
GR-D33	No	GR-DVX7	No
GR-D34	No	GR-DVX9	No
GR-D43	No	GR-DVX44	No
GR-D51	No	GR-DVX70	No
GR-D53	No	GR-DVX88	No
GR-D60	No	GR-DX25	No
GR-D63	No	GR-DX27EK	No
GR-D200	No	GR-DX28	No
GR-D201	No	GR-DX48	No
GR-D225EK	No	GR-DX67	No
GR-D230EK	No	GR-DVX400	No
GR-D239	No	GR-DVX407	No
GR-D240	No	GR-DVX507	No
GR-D240EK	No	GR-DVX707	No
GR-D246E	No	GR-FX10	No
GR-D247E	No	GR-FX11	No
GR-D248E	No	GR-FX14	No
GR-D250E	No	GR-FX15	No
GR-D260E	No	GR-FX16	No
GR-D270	No	GR-FX17	No
GR-D280E	No	GR-FX23	No
GR-D290E	No	GR-FX60	No
GR-DF420	No	GR-FXM15	No
GR-DF425EK	No	GR-FXM16	No
GR-DF540EX	No	GR-FXM37	No
GR-DF565	No	GR-FXM40	No
GR-DV3	No	GR-FXM41	No
GR-DV400	No	GR-FXM65	No
GR-DVF1	No	GR-FXM75	No
GR-DVF10	No	GR-SX20	No
GR-DVL20	No	GR-SX21	No
GR-DVL100	No	GR-SXM26	No
GR-DVL105	No	GR-SXM260	No
GR-DCL107	No	GR-SXM47	No
GR-DVM55	No	GR-SXM50	No
GR-DVL108	No	GR-SXM607	No
GR-DVL109	No	GY-HD100	No
GR-DVL140	No	GZ-MC100	No
GR-DVL145	No	GR-MX100EK	No
GR-DVL150	No	GZ-MC200	No
GR-DVL155	No	GZ-MX200EK	No
GR-DVL157	No	GZ-MC500	No
GR-DVL160	No	GR-MC500EK	No
GR-DVL166	No	GZ-MG20	No
GR-DVL167	No	GR-MG20E	No
GR-DVL200	No	GR-MG30	No
GR-DVL300	No	GR-MG50	No
GR-DVL307	No	GR-MG70	No
GR-DVL308	No	GZ-MC30	No
GR-DVL320E	No	GZ-MC50	No
GR-DVL520E	No	GZ-MC70	No

PANASONIC (PAL)

MODEL	A/V-in	MODEL	A/V-in
AG-DVX102	Yes	NV-DS77B	No
GR-D290EK	Yes	NV-DS990EG	No
GR-DZ7EK	Yes	NV-DX110	No
NV-DS38	Yes	NV-GS1	No
NV-DS30A	Yes	NV-GS1B	No
NV-DS50A	Yes	NV-GS3	No
NV-DS60A	Yes	NV-GS4	No
NV-DS65A	Yes	NV-GS7B	No
NV-DS88B	Yes	NV-GS10B	No
NV-EX21EG	Yes	NV-GS11EB	No
NV-GS5	Yes	NV-GS11EG	No
NV-GS7	Yes	NV-GS17B	No
NV-GS50	Yes	NV-GS17EB	No
NV-GS55	Yes	NV-GS21B	No
NV-GS55GC	Yes	NV-GS21EB	No
NV-GS11GN	Yes	NV-GS22EB	No
NV-GS15GN	Yes	NV-GS24	No
NV-GS120GN	Yes	NV-GS27B	No
NV-GS200GN	Yes	NV-GS30	No
NV-GS250GN	Yes	NV-GS30B	No
NV-GS400GN	Yes	NV-GS33EB	No
NV-GS50A	Yes	NV-GS35EB	No
NV-GS70	Yes	NV-GS37B	No
NV-GS70A	Yes	NV-GS40B	No
NV-GS50B	Yes	NV-GS150B	No
NV-GS70B	Yes	NV-GS150GN	No
NV-MX7B	Yes	NV-GS25GN	No
NV-MX8	Yes	NV-GS75GN	No
nV-MX300B	Yes	NV-GS180B	No
NV-MX300	Yes	NV-GS180EG	No
NV-MX500B	Yes	NV-GS250	No
NV-VZ17B	Yes	NV-GS500EG-S	No
SD-RS100	Yes	NV-MX1	No
VD-RM50	Yes	NV-MX2	No
VD-RM70	Yes	NV-MX2B	No
VD-RM55B	Yes	NV-MX3A	No
VD-RM75B	Yes	NV-MX5	No
GR-FX-16	No	NV-MX5B	No
GR-FX17	No	VD-RM30B	No
GR-FXM40	No	VDR-M30B	No
GR-FXM41	No	VDR-M70	No
GR-D240EK	No		
GR-DF420EK	No		
NV-DA1B	No		
NV-DC99B	No		
NV-DS1B	No		
NV-DS11	No		
NV-DS12B	No		
NV-DS27	No		
NV-DS27B	No		
NV-DS28	No		
NV-DS28B	No		
NV-DS29	No		
NV-DS30	No		
NV-DS37	No		
NV-DS60B	No		
NV-DS65B	No		

SAMSUNG (PAL)

MODEL	A/V-in	MODEL	A/V-in
VP-M110S	Yes	VP-D353	No
VP-X105L	Yes	VP-D354	No
VP-X110L	Yes	VP-D451	No
VP-651	No	VP-D453	No
VP-D230	No	VP-D454	No
VP-D270i	No	VP-D653	No
VP-D323	No	VP-D6550	No
VP-D325i	No	VP-M105S	No
VP-D351	No	VP-MS12S	No
VP-D352	No		

SONY (PAL)

MODEL	A/V-in	MODEL	A/V-in
CCD-TR2300E	Yes	DCR-HC65E	Yes
CCD-TR3300E	Yes	DCR-HC85E	Yes
CCD-TR3400E	Yes	DCR-HC90E	Yes
CCD-TR840E	Yes	DCR-HC96E	Yes
CCD-TR920E	Yes	DCR-HC1000E	Yes
CCD-TRV45E	Yes	DCR-PC8E	Yes
CCD-TRV54E	Yes	DCR-PC9E	Yes
CCD-TRV55E	Yes	DCR-PC55E	Yes
CCD-TRV56E	Yes	DCR-PC100E	Yes
CCD-TRV64E	Yes	DCR-PC101E	Yes
CCD-TRV65E	Yes	DCR-PC104E	Yes
CCD-TRV66E	Yes	DCR-PC105E	Yes
CCD-TRV87E	Yes	DCR-PC108E	Yes
CCD-TRV89E	Yes	DCR-PC109E	Yes
CCD-TRV94E	Yes	DCR-PC110E	Yes
CCD-TRV99E	Yes	DCR-PC115E	Yes
DCR-DVD7E	Yes	DCR-PC120E	Yes
DCR-DVD101E	Yes	DCR-PC330E	Yes
DCR-DVD201E	Yes	DCR-PC350E	Yes
DCR-DVD203E	Yes	DCR-PC1000E	Yes
DCR-DVD403E	Yes	DCR-TRV8E	Yes
DCR-DVD305E	Yes	DCR-TRV11E	Yes
DCR-DV405E	Yes	DCR-TRV16E	Yes
DCR-DVD505E	Yes	DCR-TRV18E	Yes
DCR-DVD602E	Yes	DCR-TRV20E	Yes
DCR-DVD653E	Yes	DCR-TRV22E	Yes
DCR-DVD703E	Yes	DCR-TRV25E	Yes
DCR-DVD803E	Yes	DCR-TRV27E	Yes
DCR-IP1E	Yes	DCR-TRV30E	Yes
DCR-IP5E	Yes	DCR-TRV33E	Yes
DCR-IP7E	Yes	DCR-TRV38E	Yes
DCR-IP45E	Yes	DCR-TRV39E	Yes
DCR-IP55E	Yes	DCR-TRV40E	Yes
DCR-IP210E	Yes	DCR-TRV50E	Yes
DCR-IP220E	Yes	DCR-TRV60E	Yes
DCR-HC7	Yes	DCR-TRV70E	Yes
DCR-HC30E	Yes	DCR-TRV75E	Yes
DCR-HC32E	Yes	DCR-TRV80E	Yes
DCR-HC33E	Yes	DCR-TRV116E	Yes
DCR-HC40E	Yes	DCR-TRV118E	Yes
DCR-HC42E	Yes	DCR-TRV120E	Yes
DCR-HC43E	Yes	DCR-TRV230E	Yes

DCR-TRV235E	Yes	CCD-TR718E	No
DCR-TRV240E	Yes	CCD-TR720E	No
DCR-TRV241E	Yes	CCD-TR728E	No
DCR-TRV330E	Yes	CCD-TR730E	No
DCR-TRV340E	Yes	CCD-TR740E	No
DCR-TRV341E	Yes	CCD-TR820E	No
DCR-TRV345E	Yes	CCD-TR825E	No
DCR-TRV350E	Yes	CCD-TR845E	No
DCR-TRV351E	Yes	CCD-TR913E	No
DCR-TRV355E	Yes	CCD-TR918E	No
DCR-TRV356E	Yes	CCD-TR950E	No
DCR-TRV410E	Yes	CCD-TRV10E	No
DCR-TRV420E	Yes	CCD-TRV12E	No
DCR-TRV430E	Yes	CCD-TRV13E	No
DCR-TRV460E	Yes	CCD-TRV14E	No
DCR-TRV461E	Yes	CCD-TRV15E	No
DCR-TRV480E	Yes	CCD-TRV16E	No
DCR-TRV510E	Yes	CCD-TRV23E	No
DCR-TRV520E	Yes	CCD-TRV24E	No
DCR-TRV530E	Yes	CCD-TRV26E	No
DCR-TRV620E	Yes	CCD-TRV27E	No
DCR-TRV720	Yes	CCD-TRV35E	No
DCR-TRV725E	Yes	CCD-TRV36E	No
DCR-TRV730E	Yes	CCD-TRV37E	No
DCR-TRV740E	Yes	CCD-TRV67E	No
DCR-TRV820E	Yes	CCD-TRV69E	No
DCR-TRV828E	Yes	CCD-TRV77E	No
DCR-TRV830E	Yes	CCD-TRV78E	No
DCR-TRV890E	Yes	CCD-TRV95E	No
DCR-TRV900E	Yes	CCD-TRV98E	No
DCR-TRV940E	Yes	CCD-TRV101E	No
DCR-TRV950E	Yes	CCD-TRV108E	No
DCR-VX2000E	Yes	CCD-TRV118E	No
DSR-PD170P	Yes	CCD-TRV118E	No
DSR-PDX10	Yes	CCD-TRV128E	No
HDR-FX1E	Yes	CCD-TRV208E	No
CCD-TR748E	No	CCD-TRV218E	No
CCD-TR2200E	No	CCD-TRV219E	No
CCD-TR3100E	No	CCD-TRV228E	No
CCD-TR311E	No	CCD-TRV238E	No
CCD-TR315E	No	CCD-TRV318E	No
CCD-TR317E	No	CCD-TRV408E	No
CCD-TR3200E	No	CCD-TRV418E	No
CCD-TR401E	No	CCD-TRV428E	No
CCD-TR402E	No	CCD-TRV460E	No
CCD-TR411E	No	DCR-DVD91E	No
CCD-TR412E	No	DCR-DVD92E	No
CCD-TR415E	No	DCR-DVD105E	No
CCD-TR417E	No	DCR-DVD202E	No
CCD-TR425E	No	DCR-DVD205E	No
CCD-TR427E	No	DCR-DVD404E	No
CCD-TR427E	No	DCR-DVD602E	No
CCD-TR501E	No	DCR-PC2E	No
CCD-TR502E	No	DCR-PC4E	No
CCD-TR503E	No	DCR-PC53E	No
CCD-TR506E	No	DCR-PC103E	No
CCD-TR511E	No	DCR-PC107E	No
CCD-TR512E	No	DCR-HC14E	No
CCD-TR515E	No	DCR-HC15E	No
CCD-TR516E	No	DCR-HC17E	No
CCD-TR555E	No	DCR-HR18E	No
CCD-TR617E	No	DCR-HC19E	No
CCD-TR618E	No	DCR-HC20E	No
CCD-TR620E	No	DCR-HC21E	No
CCD-TR640E	No	DRC-HC22E	No
CCD-TR713E	No	DCR-HC24E	No
CCD-TR717E	No	DCR-HC27E	No

DCR-HC35E	No	DCR-TRV12E	No
DCR-HC37E	No	DCR-TRV14E	No
DCR-HC39E	No	DCR-TRV15E	No
DCR-HC44E	No	DCR-TRV16E	No
DCR-HC45E	No	DCR-TRV17E	No
DCR-HC46E	No	DCR-TRV18E	No
DCR-HC51E	No	DCR-TRV19E	No
DCR-HC53E	No	DCR-TRV24E	No
DCR-HC62E	No	DCR-TRV140E	No
DCR-HC94E	No	DCR-TRV145E	No
DCR-PC3E	No	DCR_TRV150E	No
DCR-PC5E	No	DCR-TRV238E	No
DCR-PC6E	No	DCR-TRV239E	No
DCR-PC7E	No	DCR-TRV245E	No
DCR-PC10E	No	DCR-TRV250E	No
DCR-SC100E	No	DCR-TRV270E	No
DCR-SR30E	No	DCR-TRV285E	No
DCR-SR70E	No	DCR-TRV738E	No
DCR-TRV5E	No	DCR-TRV1000E	No
DCR-TRV6E	No	DCR-VX9000E	No
DCR-TRV7E	No	HCR-HC1E	No
DCR-TRV9E	No	HCR-HC9E	No
DCR-TRV11E	No		

NTSC Systems

CANON (NTSC)

MODEL	A/V-in	MODEL	A/V-in
Elura	Yes	XL1	Yes
Elura 2	Yes	XL2	Yes
Elura 2 MC	Yes	XL1S	Yes
Elura 10	Yes	ZR10	Yes
Elura 20 MC	Yes	ZR20	Yes
Elura 40 MC	Yes	ZR25 MC	Yes
Elura 60	Yes	ZR30 MC	Yes
Elura 65	Yes	ZR40	Yes
Elura 70	Yes	ZR45 MC	Yes
Elura 80	Yes	ZR50 MC	Yes
Elura 85	Yes	ZR60	Yes
Elura 90	Yes	ZR65 MC	Yes
Elura 100	Yes	ZR70 MC	Yes
GL1	Yes	ZR80	Yes
GL2	Yes	ZR85	Yes
Optura 10 MC	Yes	ZR90	Yes
Optura 20 MC	Yes	ZR100	Yes
Optura 30	Yes	ZR200	Yes
Optura 40	Yes	ZR300	Yes
Optura 50	Yes	ZR400	Yes
Optura 60	Yes	ZR700	Yes
Optura 100 MC	Yes	ES75	No
Optura 200 MC	Yes	ES8400	No
Optura 300	Yes	ES8600	No
Optura 400	Yes	Optura	No
Optura 500	Yes	Ultura	No
Optura PI	Yes	Vistura	No
Optura Xi	Yes	ZR500	No
		ZR600	No

HITACHI (NTSC)

MODEL	A/V-in	MODEL	A/V-in
-------	--------	-------	--------

DZMV100A DVD	Yes
DZMV200A DVD	Yes
DZMV230A DVD	Yes
DZMV270A DVD	Yes
DZMV350A DVD	Yes
DZMV380A DVD	Yes
DZMV580A DVD	Yes

JVC (NTSC)

MODEL	A/V-in	MODEL	A/V-in
GR-D70	Yes	GR-D270	No
GR-D73	Yes	GR-DMV96	No
GR-D90	Yes	GR-DVF10U	No
GR-D93	Yes	GR-DVL100	No
GR-D200	Yes	GR-DVL120	No
GR-DV90	Yes	GR-DVL300	No
GR-DV91U	Yes	GR-DVL320	No
GR-DV500	Yes	GR-DVL500	No
GR-DV800	Yes	GR-DVL 505	No
GR-DV2000	Yes	GR-DVL510	No
GR-DV3000	Yes	GR-DVL520	No
GR-DVL915	Yes	GR-DVL720	No
GR-DVL920	Yes	GR-DVL725	No
GR-DVM75	Yes	GR-DVL805	No
GR-DVP7	Yes	GR-DVM55	No
GR-DVP9	Yes	GR-DVM70U	No
GR-DX75	Yes	GR-DVM76	No
GR-DVX90	Yes	GR-DVM80	No
GR-DVX90	Yes	GR-DVM90	No
GR-DX75	Yes	GR-DVM96	No
GR-DX95US	Yes	GR-DVP3	No
GR-DX300	Yes	GR-DVX400	No
GR-HD1	Yes	GR-DVX407	No
GR-300U	No	GR-DVX507	No
GR-AX880	No	GR-DVX707	No
GR-AXM210	No	GR-SXM250	No
GR-AXM710	No	GR-SXM40	No
GR-AXM910	No	GR-SXM2600U	No
GR-D30	No	GR-SXM320	No
GR-D33	No	GR-SXM527	No

PANASONIC (NTSC)

MODEL	A/V-in	MODEL	A/V-in
AGDZ-50	Yes	VDR-M50 DVD	Yes
AG-DV1DC	Yes	VDR-M70PP	Yes
PV-DC352	Yes	PV-DV51	No
PV-DV953	Yes	PV-DV52	No
PV-GS50	Yes	PV-DV53	No
PV-GS55	Yes	PV-DV73	No
PV-GS70	Yes	PV-DV100	No
PV-GS120	Yes	PV-DV101	No
PV-GS200	Yes	PV-DV102	No
PV-GS250	Yes	PV-DV103	No
PV-GS400	Yes	PV-DV202	No
PVL-701	Yes	PV-DV203	No
PVL-851	Yes	PV-DV400D	No
VDR-M30 DVD	Yes	PV-DV402	No
		PV-DV910	No

PV-GS9	No	PV-GS150	No
PV-GS120	No	PVL-353	No
PV-GS14	No	PVL-453	No
PV-GS15	No	PVL-550	No
PV-GS19	No	PVL-552	No
PV-GS31	No	PVL-652	No
PV-GS35	No	PVL-679	No
PV-GS65	No	VDR-M53	No

SAMSUNG (NTSC)

MODEL	A/V-in	MODEL	A/V-in
SCD-27	Yes	SCD-86	No
SC-X105L	No	SCD-90	No
SC-X110L	No	SCD-590	No
SCD-23	No	SCL-810	No
SCD-33	No		

SHARP (NTSC)

MODEL	A/V-in	MODEL	A/V-in
VL-E600	Yes	VL-Z5U	Yes
VL-NZ105	Yes	VL-Z7U	Yes
VL-WD255U	Yes	VL-A110U	No
VL-WD450U	Yes	VL-AH150U	No
VL-WD650U	Yes	VL-AH160U	No
VL-Z3U	Yes	VL-NZ50	No
		VL-NZ55	No

SONY (NTSC)

MODEL	A/V-in	MODEL	A/V-in
CCD-TR5	Yes	DCR-DVD300	Yes
CCD-TR917	Yes	DCR-DVD301	Yes
CCD-TR940	Yes	DCR-DVD305	Yes
CCD-TRV41	Yes	DCR-DVD403	Yes
CCD-TRV62	Yes	DCR-DVD602	Yes
CCD-TRV65	Yes	DCR-DVD653	Yes
CCD-TRV72	Yes	DCR-DVD703	Yes
CCD-TRV75	Yes	DCR-DVD803	Yes
CCD-TRV81	Yes	DCR-HC30	Yes
CCD-TRV82	Yes	DCR-HC32	Yes
CCD-TRV85	Yes	DCR-HC40	Yes
CCD-TRV87	Yes	DCR-HC42	Yes
CCD-TRV93	Yes	DCR-HC65	Yes
CCD-TRV99	Yes	DCR-HC85	Yes
CCD-TRV615	Yes	DCR-HC90	Yes
CCD-TRV715	Yes	DCR-HC1000	Yes
CCD-TRV815	Yes	DCR-IP1	Yes
DCM-M1	Yes	DCR-IP5	Yes
DCR-DVD7	Yes	DCR-IP7BT	Yes
DCR-DVD92	Yes	DCR-IP45	Yes
DCR-DVD100	Yes	DCR-IP55	Yes
DCR-DVD101	Yes	DCR-IP210	Yes
DCR-DVD103	Yes	DCR-IP220	Yes
DCR-DVD200	Yes	DCR-PC3	Yes
DCR-DVD201	Yes	DCR-PC5	Yes
DCR-DVD203	Yes	DCR-PC9	Yes

DCR-PC100	Yes	GR-DV900	Yes
DCR-PC101	Yes	GV-D200	Yes
DCR-PC105	Yes	GV-D1000	Yes
DCR-PC109	Yes	VX700	Yes
DCR-PC110	Yes	HDR-FX1	Yes
DCR-PC115	Yes	VX2000	Yes
DCR-PC120BT	Yes	VX2100	Yes
DCR-PC330	Yes	CCD-FX240	No
DCR-PC350	Yes	CCD-FX340	No
DCR-PC1000	Yes	CCD-FX640	No
DCR-TR7000	Yes	CCD-TR57	No
DCR-TRV6	Yes	CCD-TR66	No
DCR-TRV8	Yes	CCD-TR67	No
DCR-TRV9	Yes	CCD-TR86	No
DCR-TRV10	Yes	CCD-TR87	No
DCR-TRV11	Yes	CCD-TR96	No
DCR-TRV15	Yes	CCD-TR97	No
DCR-TRV16	Yes	CCD-TR316	No
DCR-TRV17	Yes	CCD-TR416	No
DCR-TRV18	Yes	CCD-TR516	No
DCR-TRV20	Yes	CCD-TR916	No
DCR-TRV22	Yes	CCD-TRV11	No
DCR-TRV25	Yes	CCD-TRV15	No
DCR-TRV27	Yes	CCD-TRV16	No
DCR-TRV30	Yes	CCD-TRV17	No
DCR-TRV33	Yes	CCD-TRV25	No
DCR-TRV38	Yes	CCD-TRV35	No
DCR-TRV39	Yes	CCD-TRV36	No
DCR-TRV40	Yes	CCD-TRV37	No
DCR-TRV50	Yes	CCD-TRV43	No
DCR-TRV70	Yes	CCD-TRV46	No
DCR-TRV60	Yes	CCD-TRV57	No
DCR-TRV80	Yes	CCD-TRV58	No
DCR-TRV85	Yes	CCD-TRV67	No
DCR-TRV103	Yes	CCD-TRV68	No
DCR-TRV110	Yes	CCD-TRV107	No
DCR-TRV115	Yes	CCD-TRV108	No
DCR-TRV120	Yes	CCD-TRV118	No
DCR-TRV203	Yes	CCD-TRV128	No
DCR-TRV210	Yes	CCD-TRV138	No
DCR-TRV230	Yes	CCD-TRV140	No
DCR-TRV240	Yes	CCD-TRV215	No
DCR-TRV310	Yes	CCD_TRV228	No
DCR-TRV315	Yes	CCD-TRV308	No
DCR-TRV320	Yes	CCD-TRV315	No
DCR-TRV330	Yes	CCD-TRV318	No
DCR-TRV340	Yes	CCD-TRV328	No
DCR-TRV350D8	Yes	CCD-TRV338	No
DCR-TRV360	Yes	CCD-TRV408	No
DCR-TRV460	Yes	CCD-TRV428	No
DCR-TRV510	Yes	CCD-TRV517	No
DCR-TRV530	Yes	CCD-TRV608	No
DCR-TRV720	Yes	CCD-TRV716	No
DCR-TRV730	Yes	DCR-HC20	No
DCR-TRV740	Yes	DCR-HC21	No
DCR-TRV820	Yes	DCR-PC1	No
DCR-TRV828	Yes	DCR-PC7	No
DCR-TRV830	Yes	DCR-PC10	No
DCR-TRV840	Yes	DCR-SC100	No
DCR-TRV900	Yes	DCR-TRV5	No
DCR-TRV940	Yes	DCR-TRV7	No
DCR-TRV950	Yes	DCR-TRV19	No
DCR-VX1000	Yes	DCR-TRV130	No
DCR-VX2000	Yes	DCR-TRV140	No
DSR-PD100A	Yes	DCR-TRV145	No
DSR-PD150	Yes		
GV-A500	Yes		

DCR-TRV250
DCR-TRV260
DCR-TRV280

No
No
No

DCR-TRV355
DCR-VX700

No
No